1 Remove Packaging



- The appliance is fitted with transit bolts to prevent internal damage during transport. **Be careful, heavy load!**
- Packing and all transit bolts must be removed before using the washing machine.
- When unpacking the base, be sure to remove the additional packing support in the middle of the base packing.

ⓘ Store original packing for future move.
Dispose of packing material according to local regulations.

2 Transit bolts

1



To prevent internal damage during transport, the special 4 bolts are locked. If they are not removed, it may cause heavy vibration, noise and machine to malfunction.

2



Remove the 4 bolts along with the rubber bungs by slightly twisting the bung.

3



Unscrew the 4 bolts using the spanner supplied.

4



Close the holes with the caps supplied.



ⓘ *Keep the 4 bolts and the spanner for the future use. Refit transit bolts before transporting the appliance.*

3 Requirements for installation site



Level floor: Permissible floor gradient under entire washing machine is 1˚ .

Power socket: Must be within 100 cm of either side of location of washing machine. Do not overload the socket with more than one appliance.

Additional Clearance: For wall, floor and door space is needed. (10cm: rear / 2cm:right & left side). Do not place or store laundry products on top of the washing machine at any times. They can damage the finish or controls of the machine.

4 Electrical connection

1. Do not use an extension cord or double adapter.
2. Have damaged supply cords replaced by the manufacturer or its service agents or a similarly qualified person to prevent danger.
3. Always unplug the machine and turn off the water supply after use.
4. Connect the machine to an earthed socket in accordance with current wiring regulations.
5. The appliance must be positioned so that the plug is easily accessible.

- Repairs to the washing machine must only be carried out by qualified personnel. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local service centre.
- Do not install your washing machine in rooms where temperature below freezing may occur. Frozen hoses may burst under pressure. The electronic control unit may become unreliable at temperatures below freezing point.
- If the appliance is delivered in the winter months and temperatures are below freezing: Leave the washing machine standing at room temperature for a few hours before putting it into operation.



BS Plug Safety Details (For U.K. User)

This appliance must be earthed As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows: The green and yellow wire must be connected to the terminal in the plug marked E or by the earth symbol ⏚ or coloured green or green and yellow. The wire coloured blue must be connected to the terminal marked with the letter N or coloured black. The wire coloured brown must be connected to the terminal marked with the letter L or coloured red. If a 13 amp (BS 1363) plug is used, fit a 13 amp BS 1362 fuse.

CAUTION

The appliance is not intended for use by young children or infirm persons without supervision.
Young Children should be supervised to ensure that they do not play with appliance.

5 Connecting water supply hose

The hose supplied with the machine must be used. Old hoses may not be reused



Water supply pressure must be between 1.0-10 bar (100kPa~1000kPa)

Don't strip or crossthread when connecting inlet hose to the valve.

If the water supply pressure is more than 1000kPa, a decompression device should be installed.







- Two rubber seals are supplied with the water inlet hoses. They are used for preventing water leaks.
- Make sure the connection to taps is tight enough.
- Periodically check the condition of the hose and replace the hose if necessary.
- Make sure that there is no kink on the hose and that it is not crushed.

ⓘ If after completing connection water leaks from the hose, repeat the same steps. Use the most conventional type of tap for water supply. In case the faucet is square or too big, remove the spacing ring before inserting the tap into the adaptor.

6 Installation of drain hose









- The drain hose should not be placed higher than 100 cm above the floor.
- Proper securing of the drain hose will protect the floor from damage due to any water leakage.
- If the drain hose is too long do not force back into the washing machine. This will cause unusual noise.

7 Level adjustment





Adjustable feet



Adjustable feet

- Proper level-adjustment of the washing machine prevents excessive noise and vibration. Install the appliance on a solid and level floor surface, preferably in a corner of the room.
- If the floor is uneven, adjust feet as required. (Do not insert pieces of wood etc. under the feet). Make sure that all four feet are stable and resting on the floor. Then check that the appliance is perfectly level. (Use a spirit level).

Safety instuctions for the installation

Install or store appliance where it will not be exposed to sub-zero temperatures or exposed to the weather. Fit ground of the washing machine correctly to conform with all statutory regulations and ordinances. Ensure that the base opening is free from obstruction by carpeting if the washing machine is installed on a carpeted floor. In countries where there is a risk of cockroach infestation or other vermin, pay particular attention to keep the appliance and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin is not covered by the appliance guarantee.

CAUTION about positioning the appliance

Install the washing machine on a flat hard floor. Make sure that air circulation around the washing machine is not impeded by carpets, rug etc.

- Never try to correct any unevenness in the floor using pieces of wood, cardboard or similar materials under the washing machine.
- If it is not possible to position the washing machine away from a gas cooker or coal burning stove, an insulation panel (85x60cm) covered with aluminum foil on the side facing the cooker or stove, must be inserted between the two appliances.
- The washing machine must not be installed in rooms where the temperature may drop below 0°C.
- Please ensure that when the washing machine is installed an engineer can gain easy access in the event of a breakdown.
- Adjust all four feet using the transit bolt spanner provided to ensure that the appliance is stable, with 20mm clearnace between the top of the washing machine and underside of the worktop.

CAUTION about the power cord

We recommend connecting most appliances to a dedicated circuit. That is, a single outlet supplying power only to the appliance concerned, without any additional outlets or branch circuits. Check the specifications of this owner's manual. Do not overload wall sockets. Overloaded wall sockets, loose or damaged wall sockets or extension cords, frayed power cords, damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized servicer. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, squashed in a jamb of a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance. We recommend to use a residual current operated device in the mains supply.

CAUTION about location and moving

This equipment is not designed for maritime use or for use mobile installations such as caravans, aircraft etc. Turn off the stopcock if the machine is to be left for any length of time (e.g. if you are going on holiday), especially if there is no floor drain (gully) in the immediate vicinity. If relocating the appliance use the original packing material. Disable the door lock to prevent young children becoming trapped inside. Packaging material (e.g. plastic film, Styrofoam) can be dangerous for children. There is a risk of suffocation! Keep all packaging well away from children.

CAUTION about the floor surface

- The installation surface must be clean, dry and level.
- Install washing machine on a flat hard floor.
- Proper placement and levelling of the washing machine ensure long, regular and reliable operation.
- The washing machine must be perfectly level and firmly in position.
- It must not "see-saw" across corners under load.
- The installation surface must be clean, free from floor wax and other lubricant coatings.
- Do not allow the feet of the washing machine to get wet. If feet of the washing machine get wet, slipping may occur.

Technical Specification

Name of product	Front loading washing machine
Power supply	220~240 V~, 50 Hz
Size WxDxH mm:	600 x 590 x 850
Weight	63 kg

Max. Watt	2100 W (Wash) / 1100 W (Steam)
Wash capacity	8 kg
Water consumption	52 ℓ (6.5 ℓ / kg)
Permissible water pressure	1.0-10 bar (100-1000kPa)

Safety instructions for use

Read all instructions and explanations of the installation before use. Follow the instructions carefully. Keep the operating instructions handy for later use. If the appliance is sold or passed on then ensure that the new owner always receives these operating instructions. The following warnings must be strictly observed for safety reasons. They must be read before installing the appliance and putting it into operation.

- Intended use: This appliance has been designed exclusively for use in dry-interior households. Use the appliance only with cold drinking water and only for washing textiles with washing detergents designed for washing machines. Every other use is improper and may lead to injuries, whereby the liability of the manufacturer will cease.
- This appliance may only be used by adults. Do not allow children to touch the controls or to play with the product.
- Never modify the appliance on your own, as this is dangerous.
- This appliance is heavy. Transporting with care.
- Remove all packaging and transport bolts before using the appliance. Otherwise serious damage may result.
- All installation work must be carried out by a qualified fitter or technician.
- Have electrical connections done by a qualified electrician.
- Never place the appliance on the power cord.
- If the appliance is placed on a carpet then place the feet so that air can circulate underneath the appliance.
- Always unplug the machine and turn off the water supply after use. Disconnect appliance by pulling only the plug - never disconnect by pulling the power cord. Never touch the plug with wet fingers or hands.
- Do not overload the appliance.
- Wash only machine-washable textiles. If you have doubts regarding this, then observe the markings on the label.
- Never place electrical heaters, candles etc. in the vicinity of the appliance. They could cause the appliance to ignite or parts to warp.
- Protect the appliance from wet and damp. Otherwise, there is danger of electric shock and fire.
- Connect the appliance to a suitable wall socket for 220-240V. Never use an extension cord or double adapter.
- Empty all pockets. Hard or sharp objects such as coins, needles, nails, screws or stones may cause serious damage. Unbalanced mass may create heavy vibrations. If heavy vibrations remain also without load, call for an authorized customer service.
- Do not wash or dry articles that have been cleaned in, washed in, soaked in, or dabbed with combustible or explosive substances (such as wax, oil, paint, gasoline, degreasers, dry-cleaning solvents, kerosene, etc.). This may result in fire or explosion.
- Never insert products coated with mineral oils (e.g. nylon coating, plastic belts, etc.) into the machine. If a stain remover has been used then make sure that the solvent has been carefully washed out before inserting the clothes into the appliance. Oil may remain in the tub after a whole cycle resulting in fire during drying. So, do not load oily clothes.
- Do not operate the appliance at locations where flammable substances are present such as oil, benzene or highly inflammable gas. Such materials may cause fire or explosion. Never use combustible detergents.
- Only add the prescribed amount of softener. Excessive amounts may damage the clothes.
- After washing, keep the drum door open to protect the door seal.
- Make sure that all water has run off before opening the door. Never open the door if water still remains. Danger of scalding.
- Animals and children may get into the washing machine. So always check the appliance before using it.
- During washing, the glass door becomes very hot. Keep children away from the appliance when in operation.
- Never try to repair the machine yourself. Incorrect repairs may result in injuries and/or serious defects to the machine.
- The product should be serviced and repaired only by the authorised customer service using original replacement parts.
- When disposing of your old machine, the power cable must be capped and the door lock must be made unusable in order to protect children.
- When placing on a carpeted floor, make sure that the opening in the socket is not blocked.
- If the appliance has been under water then contact the customer service. There is danger of electric shock and fire.
- The cover cup of the filter as well as the dispenser drawer may not be opened during the operation.
- Keep all washing powder and detergents away from children. Danger of poisoning

Disposal

- **When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by European Directive 2002/96/EC.**
- **All electrical and electronic products should be disposed of separately from municipal waste stream via designated collection facilities appointed by the government or the local authorities.**
- **The correct disposal of your old appliance will help prevent potential adverse consequences for the environment and human health.**
- **For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.**

Troubleshooting

IE	• Water supply is not adequate in area • Water supply taps are not completely open. • Water inlet hose(s) are kinked. • The filter of the inlet hose(s) are clogged.	Check another tap in the house. Fully open tap. Straighten hose(s). Check the filter of the inlet hose(s).
OE	• Drain hose is kinked or clogged. • The drain filter is clogged.	Clean and straighten the drain hose. Clean the drain filter. For more detailed information, please refer to “Cleaning the drain pump filter”
UE	• Load is too small. • Load is out of balance. • The appliance has an unbalance detection and correction system. If individual heavy articles are loaded (ex. bath mat, both robe, etc.), this system may stop spinning or even interrupt the spin cycle altogether. • If the laundry is still too wet at the end of the cycle, add smaller articles of laundry to balance the load and repeat the spin cycle.	Add 1 or 2 similar items to help balance the load. Rearrange load to allow proper spinning
dE	• Is the door opened or not completely closed?	Close the door completely. ✻ If “ dE ”is not released, call for service.
tE		Unplug the power plug and call for service.
FE	• Water overfills due to the faulty water valve.	Close the water tap. Unplug the power plug. Call for service.
PE	• Water level sensor has malfunctioned.	
LE	• Over load in motor.	
AE	• Water leaks	Call for service.
PF	• The washer experienced a power failure.	Restart the cycle.

Rattling and clanking noise	Extraneous objects such as coins or safety pins maybe in drum or pump.
Thumping sound	Heavy wash loads may produce a thumping sound. This is usually normal.
Vibrating noise	Have all transit bolts and packing been removed?
Water leaks.	Check and tighten hose connections. Unclog drain pipe. Contact plumber if necessary.
Excessive suds	Too much detergent or unsuitable detergent.
Washing machine does not start	Power cord may not be plugged in or connection may be loose.
Washing machine won’t spin	Check that the door is firmly shut.
Door does not open	Once started, the door can not be opened for safety reasons. Wait one or two minutes before opening the door to allow the electric locking mechanism time to release.

Owner's Manual

F1403TDS(1~9)
F1203TDS(1~9)

Before use please read carefully the safety instructions! ⚠

Thank you for buying an LG fully automatic washing machine.
Please read this owner's manual carefully, it provides instructions on safe installation, use and maintenance.
Keep it handy for future reference of this machine. Make a note of the model and serial numbers of your washing machine.

For the U.K. customer
CUSTOMER SERVICES Tel. : +44-(0) 844 847 LGLG(5454) Fax. : +44-(0) 844 847 1413
LGEUK SERVICE WEB-SITE : http://www.lge.co.uk

P/No. :MFL59755582

Preparation

CHECKING THE MACHINE
Never use a defective machine! In case of any failure, first unplug the machine and turn off the water tap.

WATER CONNECTION
Turn on the water tap

HANG UP WASTE WATER HOSE
Hose elbow connection e.g. attach to water tap

INSERT PLUS INTO THE MAINS SOCKET
⚠ Never touch the plug with wet hands! Never remove the plug from the socket by pulling on the cord.

DOING LAUNDRY AND USING MACHINE WITH CARE
- empty all pockets
- remove all metal parts
- place the delicate textiles into the laundry net
- close zippers

LAUNDRY WITH DIFFERENT AMOUNTS OF SOILING

lightly
heavily

- wash new textiles separately
- do not prewash
- pretreat dirty spots
- pre wash

WATER TREATMENT
- with hardness III water
- use water softening agent

DRUM CARE
- remove extraneous objects
- leave door open to dry the drum
- check the rubber seals regularly

ECOLOGICAL WASHING
- make use of the max. washing quantity
- do not "pre wash" if possible
- use short program if possible

Washing symbols

- Washing temperature
- Do not wash
- Luke warm ironing
- Medium hot ironing
- Hot ironing
- Do not iron
- Do not tumble dry
- Hang to dry
- Drip dry
- Dry flat
- Do not bleach
- Handy to bleach

Dispenser drawer

Ⓐ Pre Wash
For normal dirty clothes use a small amount of detergent. Don't pre wash. Mount the level plate to use fluid detergents.

Ⓑ Main Wash
For very dirty clothes fill 1/4 of the portion of detergent in here and select a prewashing programm

Ⓒ Softener
Do not exceed the MAX-Level. Highly densed softeners are to be diluted with some water.

Washing program table

Program	Fabric Type	Water Temp. (Option)	Option	Maximum Load
Cotton	Color fast garments (shirts, nightdresses, pajamas...)and lightly soiled white cotton (underwear)	60°C (Cold, 30°C, 40°C, 95°C)	- Time Delay - Steam Wash - Intensive - Soak - Pre Wash - Crease Care - Rinse+Spin - Medic Rinse	Rating
Cotton Quick	Lightly soiled clothing and small loads	40°C (Cold, 30°C, 60°C)		Less than 6.0kg
Synthetic	Polyamide, Acrylic, Polyester	40°C (Cold, 30°C, 60°C)		Less than 4.0kg
Baby Care	Lightly soiled baby wear	60°C (40°C, 95°C)		Less than 4.5kg
Allergy Care	Cotton, underwear, pillow covers, bed sheets, baby wear	60°C	- Time Delay - Steam Default - Intensive - Crease Care - Rinse+Spin - Medic Rinse	Less than 4.0kg
Delicate	Delicate laundry easily damaged	30°C (Cold, 40°C)	- Time Delay - Intensive - Crease Care - Rinse+Spin	Less than 3.0kg
Hand Wash /Wool	"Hand wash" marked delicate and wool laundry	40°C (Cold, 30°C)		Less than 2.0kg
Quick 30	Colored laundry which is lightly soiled fast	30°C (Cold, 40°C)		
Refresh	Cotton mixed, Polyester mixed Dress shirts, blouses	No Choose	- Steam Default	3 items

Water Temperature: Select water temperature to suit wash cycles. Always follow garment manufacture's care label or instructions when washing.
Intensive: If the laundry is heavily soiled "Intensive" option is effective.
Set program at "Cotton 60°C + Steam Wash + Intensive" option for test in accordance or in conformity with IEC60456 and EN60456.
Pre Wash: If the laundry is heavily soiled, "Pre Wash" Cotton is recommended. Pre Wash is available in the Cotton, Cotton Quick, Synthetic, and Baby Care
Crease Care: If you want to prevent creasing, select Crease Care option.
Medic Rinse: For best results or for cleaner rinsing, you can choose Medic Rinse option. Medic Rinse is set by default in the Baby Care program.

The wool wash cycle of this machine has been approved by Woolmark for the washing of machine washable Woolmark products provided that the p
washed according to the instructions on the garment label and those issued by the manufacturer of this washing machine M0806.

Notes
Neutral detergent is recommended. The wool cycle features gentle tumbling and low-speed spin for garment care.

Warning: Keep all washing powder and detergents away from children. Danger of poisoning

Check the
and
Chec
any
Remove any clothin
to prevent



Note:
To use programs in the Steam-Cycle, please press first the "Steam Wash" butt (see additional programs).

Sort the laundry ①

note washing instruction symbols -
Degree of soiling -
Type of textile / colour -

Fill the drum ②

folds of the flexible gasket (grey) -
remove any small articles, if any.
k inside of the drum and remove -
left in items for next wash cycle.
ng or items on the flexible gasket -
clothing and the gasket damages

Fill detergent ③

Refer to the
written information
on the detergent's packing



Turn the machine ON
by pressing the Power button

Select a
Program


*Steam Cycle
Cotton
Cotton Quick
Synthetic
Baby Care
Delicate
Allergy Care
Hand Wash /Wool
Refresh
Quick 30

on

Select the
Spinning speed

Spin
800
600
1000
400
1100
1200

[F1203TDS(1~9)]

Spin
800
600
1000
400
1200
1400

[F1403TDS(1~9)]

Select an **Option**
Pre Wash / Soak / Crease Care / Rinse + Spin


Option
Pre Wash
Soak
Crease Care
Rinse+Spin

program.

Select **Rinse mode**
and **Washing temperature**


Rinse⁺+Hold
Normal+Hold
Rinse⁺⁺
Rinse⁺
Normal
Rinse
Temp.
95°c
60
40
30

roducts are

4 additional programs
Time Delay / Steam Wash / Intensive / Medic Rinse


Time Delay
Steam Wash
Intensive
Medic Rinse
Rinse⁺+Hold
Normal+Hold
Rinse⁺⁺
Rinse⁺
Normal
95°c
60
40
30
Pre Wash
Soak
Crease Care
Rinse+Spin

Press Start / Pause
to start the washing process

Wait until washing is finished


Control panel
Dispenser drawer
Drum
Cover cap

Steam Cycle


Additional programs
Display
Spinning cycle
*Steam Cycle
Cotton
Cotton Quick
Synthetic
Baby Care
Delicate
Allergy Care
Hand Wash /Wool
Refresh
Quick 30
Time Delay
Steam Wash
Intensive
Medic Rinse
Spin
800
600
1000
400
1200
1400
Option
Rinse
Temp.
*Press & Hold 3sec. for Tub Clean Function
Power button
Program Cycle
Start / Pause
Options
Rinse
Temperature

Turn off tap
- Close water supply
- Clean the machine
- Unplug machine

Additional Steps
- Turn the machine off
- Leave door open to allow drum to dry

Remove laundry
- Open the door
- Remove the laundry

Additional programs

Time Delay

Setting “Time Delay” determines when machine stops.

How to set “Time Delay”

- Press **Power** button.
- Turn the **Program** dial to select the program you require.
- Press **Time Delay** button and set time required.
- Press the **Start/Pause** button.

Intensive

If the laundry is heavily soiled “Intensive”option is effective.

- By selecting the Intensive option, the washing duration may be extended, depending on the program selected.
- To use this option, press the intensive button once before the wash program is started.

Medic Rinse

For best results or for cleaner rinsing, select the “Medic Rinse” option.

Available in the Cotton, Cotton Quick, Synthetic, Baby Care, and Allergy Care programs.
Medic Rinse is set by default in the Baby Care program.
The respective temperature indicator will light up.

Steam Washing and Refresh cycle

Refresh | Allergy Care | Baby Care | Cotton | Cotton Quick | Synthetic

Steam Cycle
Cotton Quick
Cotton
Synthetic
Baby Care
Delicate
Allergy Care
Hand Wash /Wool
Refresh
Quick 30

Steam Washing features enhance washing performance with low energy consumption. Refresh cycle reduces creases in clothes.

By pressing the Steam Wash button, Steam Function can be selected. When Steam Function is selected, Steam wash (Steam Wash) LED lights up.

Steam Wash is

- For heavily stained clothes, underwear, or baby clothes.
- Steam Wash is available with the Cotton, Cotton Quick, Synthetic, Baby Care, and Allergy Care programs.
- Refresh cycle is always Steam wash.
- Do not load delicates such as wool, silk, and easily discolored clothes.

Program	Temperature
Cotton	Cold, 30°C, 40°C, 60°C, 95°C
Cotton Quick	Cold, 30°C, 40°C, 60°C
Synthetic	Cold, 30°C, 40°C, 60°C

Program	Temperature
Baby Care	40°C, 60°C, 95°C
Refresh	No choose
Allergy Care	60°C

How to use Refresh Cycle

Allergy Care
Refresh

① Select the Refresh program

② Load 3 items or less and close the door

Time Delay
Steam Wash
Intensive

③ Press the Steam Wash button repeatedly until the required and correct number of items is displayed

④ Press the ⏯ **Start/Pause** button

Child Lock

Select this function to lock the buttons on the control panel and to prevent tampering.


3 sec.
Option

① **To activate:** press and hold the Option buttons simultaneously


3 sec.
Option

② **To deactivate:** press and hold the Option buttons simultaneously

Change to the desired program, whilst in child lock mode:


3 sec.
Option

Press and hold the Option buttons simultaneously



Press Start/Pause

Steam Cycle
Cotton Quick
Cotton
Synthetic
Baby Care
Delicate
Allergy Care
Hand Wash /Wool
Refresh
Quick 30

Select the desired program



press Start/Pause

Tub Clean

TUB CLEAN is special cycle to clean the inside of the washing machine.
A higher water level is used in this cyle at higher spin speed. **Perform this cycle regularly.**

① Empty the drum completly and close the door

② Add anti-limescale (Calgon) to the main wash compartment. Close the disp. drawer


3 sec.
Rinse
Temp.

③ Power ON with ⓘ Then press and hold Rinse and Temp. button



④ Press the ⏯ Start/ Pause button to start Tub Clean process

⑤ After the cycle is complete, leave the door open to dry

Beep on / off


Option
Rinse
Temp.

The Beep on/off function can be set only during the washing cycle.

To set the Beep On/Off function follow the below steps.

1. Turn on the washing machine (by pressing the **Power** button).
2. Press the **Start/Pause** button.
3. Press and hold the **Option** and **Rinse** button simultaneously for three seconds to set Beep on/off function.

Once the Beep on/off function is set, the setting is memorized even after Power is off.

Cleaning and Maintenance

Warning: Before cleaning the washing machine interior, unplug the electrical power cord to avoid the risk of electric shock.

Cleaning the water inlet filter


1 Turn off the water tap


2 Unscrew the water inlet hose


3 Pull out the water inlet filter


4 Clean the filter using a hard bristle brush


5 Tighten up the inlet hose

Cleaning the drain pump filter


1 Open the lower cover cap. Drain plug to pull out the hose


2 Unplug the drain plug. Then open the filter by turning to the left


3 Remove any extraneous matter from the pump filter


4 After cleaning, turn the pump filter and insert the drain plug


5 Close the lower cover cap

Cleaning the dispenser drawer


1 Pull out the dispenser drawer


2 Clean the dispenser drawer under flowing water


3 Clean inside the recess with an old toothbrush


4 Insert the dispenser drawer

5 Once you have finished cleaning, replace the drawer and run a rinse cycle without laundry.

Cleaning in general

Important: Do not use methylated spirits, solvents or similar products.

Exterior

Proper care of your washing machine can extend its service life. The outside of the machine can be cleaned with warm water and a neutral non-abrasive household detergent. Immediately wipe off any spillage. Wipe with damp cloth. Avoid striking the surface with sharp objects. Never hose down the machine!

Interior

Dry around the washing machine door opening, flexible gasket and door glass. Run washing machine through a complete cycle using hot water. Repeat process if necessary.